



Waterproofing

TREMproof®260 or TREMproof 250 GC with drainage board.

All surfaces should be clean and free of contaminants before application.

Application

- Apply a 2" dollop of TREMGrip® onto the TREMproof 260 every 8" to 12" on center.
- Place and press the drainage board onto the dollops of TREMGrip.
- Secure drainage board by applying pressure over newly installed area for 15-30 seconds.
- Applications with exposure to wind may require additional TREMGrip dollops.



SEE TREMGrip IN ACTION AT:
<https://www.youtube.com/watch?v=3TvDvWIF-no>

Tremco recommends the drainage board to be opened and relax 8-12 hours prior to application.

» Actual roll size is 4 x 50 ft.

* For backfill applications with compaction.