

ENEREDGE® DESICCANT TEST KIT AND INSTRUCTIONS

STEP 1

– Use an approved vial available from Tremco or other approved suppliers. Kimble Chase 60965D-7 with closure.



STEP 2

– Use an approved humidity indicator card available from Tremco. Expose the card to ambient air until round spot turns pink. These cards are reusable..



STEP 3

– Place the humidity indicator card into the vial with the indicator side facing out. This allows the result to be easily read.



STEP 4

– Without removing the liner, cut enough pieces of EnerEDGE® approx. 1/8" to 3/16" long to fill the vial



STEP 5

– Fill the vial to the top with pieces of EnerEDGE®. Place the cap on securely.



STEP 6

– If the round spot turns blue, typically within 1 hour, the spacer is usable.



STEP 7

– If after 1 hour, the indicator remains pink, repeat the test with fresh spacer taken 2 layers underneath the original spacer. If this fails, contact your Tremco representative.



