



Notes:
 1. Paraseal products require a minimum 24 psf compaction/ confinement in order to function as designed.
 2. Boot must fit snug around pipe or conduit without folding. Para JT Tape must be used to completely seal between boot and pipe. Tighten hose clamp as tight as possible without damaging the boot.

This detail is intended for conceptual purposes only. Detail must be reviewed by a project/design professional. See www.tremcosealants.com for the most up-to-date product information.

1	3/4/2014	Update Detail	KAB
Rev	Date	Description	By