



OVERLAP JOINT CONTINUATION

1. APPLY SPECTREM 1 ACROSS THE END OF OVERLAPPING EXTRUSIONS
2. PLACE THE SPECTREM SIMPLE SEAL OVER THE TOP OF THE EXISTING EXTRUSION AND FIRMLY PRESS INTO PLACE TO ENSURE COMPLETE CONTACT
3. TOOL EXCESS SPECTREM 1

BUTT JOINT CONTINUATION

1. USE SPECTREM 1 TO BUTTER THE BUTT ENDS OF THE SPECTREM SIMPLE SEAL
2. INSTALL THE SPECTREM SIMPLE SEAL, ENSURING THE ENDS BUTT TIGHTLY TOGETHER
3. TOOL THE SPECTREM 1 OF THE BUTT JOINT FLUSH WITH THE SURFACE

The architecture, engineering, and design of the project using the Tremco products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Tremco specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Tremco to ensure you have the most recent version.

Spectrem Simple Seal



Tremco Technical Support: 866-209-2404

Detail: Spectrem Simple Seal Joint Continuation Detail

Drawn by: HDE

Checked by: AM

Scale: NTS

Date: 4/19/2022

File Name:

SSS-J-02



Construction Products Group

www.tremcocpg.com