



BUTT JOINT INTERSECTION

1. APPLY THE VERTICAL JOINT OF SPECTREM SIMPLE SEAL
2. BUTT THE HORIZONTAL EXTRUSION TO THE VERTICAL EXTRUSION
3. SLIDE THE HORIZONTAL SECTION INTO PLACE, ENSURING IT BUTTS TIGHTLY AGAINST THE VERTICAL SECTION
4. TOOL THE SPECTREM 1 OF THE BUTT JOINT FLUSH WITH THE SURFACE OF THE PREFORMED JOINT

The architecture, engineering, and design of the project using the Tremco products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Tremco specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Tremco to ensure you have the most recent version.

Spectrem Simple Seal

 Tremco Technical Support: 866-209-2404	Detail: Spectrem Simple Seal Butt Joint Intersection				File Name:		 Construction Products Group
	Drawn by: HDE	Checked by: AM	Scale: NTS	Date: 4/19/2022	SSS-J-03		
www.tremcocpg.com							