



APPLICATION INSTRUCTIONS

ExoAir® 2000

Flexible Fluid-Applied Synthetic Air
and Vapor Permeable Membrane

1. PURPOSE

- 1.1 The purpose of this document is to establish uniform procedures for installing ExoAir® 2000 fluid-applied, synthetic air and vapor permeable membrane.
- 1.2 The techniques involved may require modifications to adjust to jobsite conditions Tremco recognizes that site specific conditions, weather patterns, contractor preferences, and membrane detailing may require deviation or alteration from these prescribed installation procedures. When such circumstances exist on a project, Tremco recommends that the local Tremco Sales Representative or Tremco Technical Service be contacted for assistance and approval as required.
- 1.3 ExoAir 2000 is compatible with and part of ExoAir Air Barrier Systems, a complete line of air barrier systems provided by Tremco.

2. SCOPE

- 2.1 This document will provide the necessary instructions for the application of ExoAir 2000 and its related air barrier system components.

3. POSSIBLE SYSTEM COMPONENTS

- 3.1 Recommended materials and their uses are as follows. For more information on the following materials, please contact your local Tremco Sales Representative or visit our website for product specific data sheet and application instructions at www.tremcosealants.com.
- 3.2 Detail Sealant
 - Dymonic® 100
 - ExoAir DualFlash®
 - Spectrem® 1*
 - TREMflex® 834
- 3.3 *May only be used as directed in sections 7.1, 7.2, and 8.6
- 3.4 Transition Membrane
 - ExoAir 110
 - ExoAir 110AT
 - Proglaze ETA (Engineered Transition Assemblies)
- 3.5 Other Accessories
 - ExoAir Flex Foam
 - ExoAir LEF (Low-Expanding Foam)
 - Willseal® 600

4. LIMITATIONS

- 4.1 UV exposure should not exceed 6 months before facade installation If the 6 month limit is exceeded, contact Tremco Technical Service at 866-209-2404, or visit the Technical Resources area of our website at www.tremcosealants.com and "Ask The Expert"
- 4.2 Do not apply to damp, contaminated, or frost covered surfaces.

- 4.3 ExoAir 2000 is not to be used as a permanently exposed surface. Contact your local Tremco Sales Representative for project-specific requirements.
- 4.4 The membrane shall be protected from rain and washout prior to drying, When applying ExoAir 2000 to surface below 25 °F (-4 °C), please refer to the Technical Bulletin - Cold Temperature Recommendations for Air Barrier Applications at www.tremcosealants.com or contact Tremco Technical Services at 866-209-2404.
- 4.5 ExoAir 2000 is not to be applied directly to fireproofing materials. Contact Tremco Technical Service at www.tremcosealants.com for alternative recommendations.
- 4.6 Keep product from freezing prior to being applied to the substrate. It is best to store ExoAir 2000 off the floor at an ambient temperature above 40 °F (5 °C)

5. STORAGE

- 5.1 Store ExoAir 2000 in original, undamaged package in a clean, dry, protected location with temperatures between 40 to 100 °F (5 to 37 °C).

6. SUBSTRATE PREPARATION

- 6.1 Roofing systems shall be capped and sealed, or top of walls protected, in such a way as to eliminate the ability of water to saturate the wall or interior space, both before and after air barrier system installation. Coordinate installation of ExoAir 2000 with the roofing trade to ensure compatibility and continuity with the roofing system.
- 6.2 Continuity of the air barrier system is crucial to the performance of the facade. Proper connections to the other envelope systems, such as the waterproofing, flashing, roof, and window/curtain wall systems shall be documented and approved by each manufacturer. Visit www.tremcosealants.com for various system testing performed at the Tremco Test Facility or to submit a project connections detail for testing.
- 6.3 Surface to be coated must be dry, clean, smooth, firm, free of release agents, dust, mud, loose mortar, wires, fins, metal, projections, or any other substances that might prevent the placement and bonding of the membrane.
- 6.4 ExoAir 2000 may be applied to most typical building materials such as exterior sheathing boards, CMU, concrete, exterior grade plywood, OSB, metal surfaces, Nudura Insulated Concrete Forms (ICF), and insulated concrete forms.
- 6.5 Exterior sheathing shall be installed according to the manufacturer's installation instructions. All board edges shall be sound and anchored in a way to provide minimum deflection. All board edges shall be cut cleanly and excess debris shall be removed.
- 6.6 CMU walls shall have all joints filled and struck flush. Mortar should cure for a minimum of 7 days. Any voids shall be patched with mortar, a non-shrinking grout, or other approved patching material.
- 6.7 All concrete substrates shall be clean and free of all release agents. any voids shall be patched with mortar, non-shrinking grout, or other approved patching material.
- 6.8 Exterior grade plywood and OSB shall be securely fastened. All board fasteners, knots, or other defects need to be detailed with Tremco Dymonic 100 or ExoAir DualFlash.
- 6.9 Metal surfaces require a pull-test to validate proper adhesion and performance. Metal surfaces need to be clean and free of oils or other contaminants.
- 6.10 Nudura Insulated Concrete Forms (ICF) or insulated concrete forms must be dry, clean, free of dust, mud, or any other substances that might prevent placement and bonding of membrane. After UV exposure, it is recommended to rasp and clean substrate to the standards above. Contact Tremco and/or Nudura Technical Services for additional information.
- 6.11 Visit www.tremcosealants.com for various system testing performed at the Tremco Test Facility or to submit a project connection detail for testing.

7. DETAIL WORK

- 7.1 Construction Gaps: All construction gaps must be detailed in the following ways, depending on substrate, joint size, and expected movement. Please choose the appropriate product based on the movement requirements and joint dimensions set forth by the design build team.

- Dymonic 100 (+100/-50% movement, 1/4" to 1" joint)
 - ExoAir DualFlash (elongation 200%)
 - Willseal 600 (+/-25% movement, 1/8" to 2-5/8" joint)
 - Proglaze ETA (varies based on system selection)
 - Tremflex 834 (+/-12% movement, 1/4" to 1" joint)
 - Dymonic Simple Seal (elongation 690%)
 - Spectrem Simple Seal (elongation 554%)
- 7.2 Fasteners: Fasteners should be flush with the surface of the substrate. Fasteners which are protruding from or sunk below the face of the substrate shall be treated with a detail coat of Dymonic 100, ExoAir DualFlash, or Tremflex 834 prior to the installation of ExoAir 2000. The detail sealants may be coated over once a skin has developed. If the fastener penetration occurs after the ExoAir 2000 membrane has been installed, detail all fastener penetrations not flush to the ExoAir 2000 membrane with Dymonic 100, ExoAir DualFlash, or Spectrem 1 sealant.
 - 7.3 Penetrations: Penetrations must be rigidly supported through membrane as to not allow movement of the penetrating item.
 - 7.4 Rough Openings, Corner, Tie-Ins to other building systems: Please consult www.tremcosealants.com for detail drawings and technical bulletins showing typical transitions and tie-ins. For job specific details or questions, please contact Tremco Technical Service at 866-209-2404.

8. MEMBRANE APPLICATION

- 8.1 Using a minimum 1/2" (13mm) nap roller, spray applicator, ExoAir 2000 is to be applied at a minimum of 14 wet mills (110 ft²/gal; 10.20 M²/US gal) to achieve a minimum of 9 dry mils. Please refer to the Technical Bulletin Spraying Guide at www.tremcosealants.com for more information on spraying ExoAir 2000.
- 8.2 Use a wet film mil gauge as well as staging of material to ensure proper application thickness.
- 8.3 When transitioning onto ExoAir self-adhered membranes, Dymonic 100 shall be used to detail the edges of the ExoAir Self-Adhered membranes prior to the installation of ExoAir 2000.
- 8.4 Seal around brick-ties and other penetrations as work progresses. Exercise care when applying around brick-ties to ensure uniform coverage.
- 8.5 Tremco has conducted in-house testing on a variety of fasteners used in commercial construction for attaching various insulation/cladding systems. The results demonstrated that if installed properly and according to the manufacturer's installation instructions, the fasteners/facade anchors tested in conjunction with the ExoAir membranes create an air and watertight seal. Tremco recommends contact Technical Service at www.tremcosealants.com for a list of evaluated fasteners/facade anchors, or to submit a fastener/facade anchor for testing.
- 8.6 If detail work is being done after the air barrier membrane has been installed, seal around brick-ties and other penetrations with an additional coat of ExoAir 2000, or detail with Dymonic 100, ExoAir DualFlash or Spectrem 1. Spectrem 1 may be used when there will not be any additional ExoAir membranes installed over it. Location, cladding type, and service life temperature may determine which detail material must be used.
- 8.7 Protect membranes to avoid damage by other trades and construction materials during subsequent operations. Insulation and/or protection products may be installed after membranes have cured, 16 to 24 hours following application, or firm and dry to the touch.
- 8.8 Connect the ExoAir Air Barrier system to the adjacent building envelope systems such as the roof membrane, below-grade waterproofing membrane, window and curtain wall systems, and other portions of the building envelope using the recommended Tremco materials. For more information on those materials and application details, please visit www.tremcosealants.com.
- 8.9 Schedule work so that the air barrier system is covered as soon as possible after installation. If the air barrier system cannot be covered within 6 months after installation, apply temporary UV protection. Contact Tremco Technical Services for additional recommendations at 866-209-2404 or visit the Technical Resources area of our website at www.tremcosealants.com and "Ask the Expert".

9. INSPECTION, TESTING AND REPAIR

- 9.1 Inspect the surface of the ExoAir 2000 thoroughly for pinholes, blisters, or other voids in the membrane. If any are detected, reapply until a monolithic coating at the specified minimum thickness is achieved. If the membrane has been completely cured, prepare the surface with solvent or water utilizing the two-rag method. Reapply at the minimum specified thickness with ExoAir 2000, extending out 4" (10 cm) beyond the pinholes, blisters, or other voids.
- 9.2 Inspect the air barrier system before covering and repair punctures or damaged areas. Make repairs with Dymonic 100 or Spectrem 1 as appropriate, extending the repair material a minimum of 4" (10 cm) beyond the puncture or damaged area in all directions.
- 9.3 If on-site testing is required, Tremco recommends ASTM D4541 Standard Test Method for Pull-Off Strength of Coatings Using Portable Adhesion Testers. ExoAir 2000 should be allowed to dry for a minimum of 72 hours or until fully cured, whichever is longer, prior to conducting test. Additional information about this testing can be found at www.tremcosealants.com in the Technical Bulletin section.

10. CLEAN UP

- 10.1 Remove any masking materials immediately after installation. Clean spillage and soiling on adjacent construction that will be exposed in the finished work using cleaning agents and procedures recommended by manufacturer of the affected construction. Ensure compatibility between cleaning agents and substrate before use.
- 10.2 Uncured Dymonic 100, ExoAir Primer, or Spectrem 1 can be cleaned using a solvent wipe.
- 10.3 Uncured Tremflex 834 or ExoAir 2000 can be cleaned using a clean, damp cloth and water.
- 10.4 Uncured ExoAir DualFlash can be cleaned with an approved solvent such as Xylene or Iso propyl Alcohol. Utensils used for tooling can also be cleaned with an approved solvent. Cured ExoAir DualFlash can be cleaned with an approved solvent such as Xylene.
- 10.5 Cured sealants or fluid-applied membranes can be cleaned using a solvent wipe. Mechanical removal methods may also be necessary.
- 10.6 Please refer to the Technical Bulletin Spraying Guide at www.tremcosealants.com for more information on cleaning the spray pump after ExoAir membrane application.

Tremco Construction Products Group (CPG) brings together Tremco CPG Inc. and its Dryvit and Nudura brands; Willseal; Prebuck LLC; Tremco Barrier Solutions, Inc.; Weatherproofing Technologies, Inc. and its Pure Air Control Services and Canam Building Envelope Specialists offerings; and Weatherproofing Technologies Canada, Inc.



tremcosealants.com | 800.321.7906



Construction Products Group

3735 Green Rd. | Beachwood, OH 44122
800.321.7906 | tremcocpg.com